



NP	Dispositivi supportati		Codice	Versione	Versioni IPERCOM									
					1.0.0	1.1.0	1.2.0	1.3.0	1.4.0	2.0.0	2.1.0	2.1.1	2.1.2	2.2.0
					dic-18	dic-18	apr-19	set-19	nov-19	dic-20	ott-21	apr-22	mag-22	dic-22
1	Posto interno	VIDEOCITOFONO IP 7" TOUCHSCREEN	1717/31-32-33-34	A31S	V	V	V	V	V	V	X	X	X	X
2	Posto interno	VIDEOCITOFONO IP 7" TOUCHSCREEN	1717/41-43	A31S	V	V	V	V	V	V	X	X	X	X
3	Lettore chiavi di prossimità	LETTORE CHIAVE DI PROSSIMITA'	1060/82		V	V	V	V	V	V	V	V	V	X
4	Posto esterno	MODULI DI CHIAMATA ELEKTA - ELEKTA STEEL	1060/12-13-17-18		V	V	V	V	V	V	V	V	V	V
5	Posto esterno	PULSANTIERA SINTHESI	1060/71-74-75-78		V	V	V	V	V	V	V	V	V	V
6	Centralino di portineria	CENTRALINO PER SISTEMA IPERCOM	1060/41		V	V	V	V	V	V	V	V	V	V
7	Posto interno	VIDEOCITOFONO IP 7" TOUCHSCREEN	1717/31-32-33-34	A64	V	V	V	V	V	V	V	V	V	V
8	Posto interno	VIDEOCITOFONO IP 7" TOUCHSCREEN	1717/41-43	A64	V	V	V	V	V	V	V	V	V	V
9	Attuatore a relè	RELE' ATTUATORE IPERCOM	1060/84	ver. 2.07	V	V	V	V	V	V	V	V	V	V
10	Altri dispositivi	Telecamere RTSP			V	V	V	V	V	V	V	V	V	V
11	Posto interno	CITOFONO VIVAVOCE MIRO IP	1160/3		X	V	V	V	V	V	V	V	V	V
12	Altri dispositivi	MODULO OROLOGIO IPERCOM	1060/85		X	V	V	V	V	V	V	V	V	V
13	Posto esterno	POSTO ESTERNO MIKRA2 IP	1060/21		X	X	X	V	V	V	V	V	V	V
14	Posto esterno	POSTO ESTERNO AL PIANO IPERCOM MIKRA2	1060/22		X	X	X	V	V	V	V	V	V	V
15	Attuatore a relè	RELE' ATTUATORE IPERCOM	1060/84	ver. 3.04	X	X	X	V	V	V	V	V	V	V
16	Dispositivi di integrazione	GATEWAY IPERCOM-2VOICE	1083/59		X	X	X	V	V	V	V	V	V	V
17	Server Ipercom	SERVER DI SISTEMA IP	1060/1		X	X	X	X	X	V	V	V	V	V
18	Posto esterno	POSTO ESTERNO AUDIO VIDEO IP ALPHA	1060/48		X	X	X	X	X	V	V	V	V	V
19	Lettore chiavi di prossimità	LETTORE CHIavi IPERCOM SINTH STEEL	1060/86		X	X	X	X	X	V	V	V	V	V
20	Attuatore a relè	RELE' ATTUATORE IPERCOM	1060/84	ver. 4.05	X	X	X	X	X	V	V	V	V	V
21	Dispositivi di integrazione	Server iPerTalk	1375/1x-1xA	-	X	X	X	X	X	V	V	V	V	V
22	Dispositivi di integrazione	Controller iPassan			X	X	X	X	X	V	V	V	V	V
23	Altri dispositivi	INTERFACCIA ASCENSORI PER SISTEMA IPERCOM	1060/37		X	X	X	X	X	V	V	V	V	V
24	Posto esterno	MODULO DI CHIAMATA ELEKTA STEEL	1060/23		X	X	X	X	X	X	V	V	V	V
25	Posto interno	VIDEOCITOFONO 7" IP VOG7	1761/31-32-33		X	X	X	X	X	X	V	V	V	V
26	Posto interno	VIDEOCITOFONO 5" VIVAVOCE IPERCOM VOG5	1761/6		X	X	X	X	X	X	V	V	V	V
27	Posto interno	VIDEOCITOFONO MAX 10"	1717/21-22-23		X	X	X	X	X	X	V	V	V	V
28	Posto interno	VIDEOCITOFONO 7" IPERCOM BASIC	1741/1-2		X	X	X	X	X	X	V	V	V	V
29	Posto interno	SOFTWARE PER VIDEOCITOFONO IP PER PC WINDOWS	1060/43		X	X	X	X	X	X	V	V	V	V
30	Software	Gateway 1060.WIN			X	X	X	X	X	X	X	V	V	V
31	Posto esterno	PULSANTIERA MIKRA plus	1060/33		X	X	X	X	X	X	X	X	X	V
32	Posto esterno	PULSANTIERA MIKRA digital	1060/34		X	X	X	X	X	X	X	X	X	V
33	Posto interno	VIDEOCITOFONO IP 5" VOG5+	1761/15-16-18-19		X	X	X	X	X	X	X	X	X	V
34	Dispositivi di integrazione	Server iPerTalk	1375/1x-1xA	V1	X	X	X	X	X	X	X	X	X	V

LBT21256

DS1060-195



NP	Supported devices		Code	Ver.		IPERCOM versions								
					1.0.0	1.1.0	1.2.0	1.3.0	1.4.0	2.0.0	2.1.0	2.1.1	2.1.2	2.2.0
					dec-18	dec-18	apr-19	sep-19	nov-19	dec-20	oct-21	apr-22	may-22	dec-22
1	Calling station	VIDEO DOOR PHONE IP 7" TOUCHSCREEN	1717/31-32-33-34	A31S	V	V	V	V	V	V	X	X	X	X
2	Calling station	VIDEO DOOR PHONE IP 7" TOUCHSCREEN	1717/41-43	A31S	V	V	V	V	V	V	X	X	X	X
3	Proximity key reader	PROXIMITY KEY READER	1060/82		V	V	V	V	V	V	V	V	V	X
4	Calling station	CALL MODULE ELEKTA - ELEKTA STEEL	1060/12-13-17-18		V	V	V	V	V	V	V	V	V	V
5	Calling station	ENTRY PANEL SINTHESI	1060/71-74-75-78		V	V	V	V	V	V	V	V	V	V
6	Switchboard	SWITCHBOARD FOR IPERCOM SYSTEM	1060/41		V	V	V	V	V	V	V	V	V	V
7	Apartment station	VIDEO DOOR PHONE IP 7" TOUCHSCREEN	1717/31-32-33-34	A64	V	V	V	V	V	V	V	V	V	V
8	Apartment station	VIDEO DOOR PHONE IP 7" TOUCHSCREEN	1717/41-43	A64	V	V	V	V	V	V	V	V	V	V
9	Relay actuator	IPERCOM RELAY ACTUATOR	1060/84	ver. 2.07	V	V	V	V	V	V	V	V	V	V
10	Other divices	RTSP CAMERAS			V	V	V	V	V	V	V	V	V	V
11	Apartment station	MIRO IP HAND-FREE DOOR PHONE	1160/3		X	V	V	V	V	V	V	V	V	V
12	Other divices	IPERCOM CLOCK MODULE	1060/85		X	V	V	V	V	V	V	V	V	V
13	Calling station	ENTRY PANEL MIKRA2 IP	1060/21		X	X	X	V	V	V	V	V	V	V
14	Calling station	PRIVATE CALL MODULE IPERCOM MIKRA2	1060/22		X	X	X	V	V	V	V	V	V	V
15	Relay actuator	IPERCOM RELAY ACTUATOR	1060/84	ver. 3.04	X	X	X	V	V	V	V	V	V	V
16	Integration devices	IPERCOM-2VOICE GATEWAY	1083/59		X	X	X	V	V	V	V	V	V	V
17	Ipercom server	SERVER SYSTEM IP	1060/1		X	X	X	X	X	V	V	V	V	V
18	Calling station	AUDIO VIDEO EXTERNAL UNIT IP ALPHA	1060/48		X	X	X	X	X	V	V	V	V	V
19	Proximity key reader	PROXIMITY KEY READER IPERCOM SINTHESI STEEL	1060/86		X	X	X	X	X	V	V	V	V	V
20	Relay actuator	IPERCOM RELAY ACTUATOR	1060/84	ver. 4.05	X	X	X	X	X	V	V	V	V	V
21	Integration devices	IPERTALK SERVER	1375/1x-1xA	-	X	X	X	X	X	V	V	V	V	V
22	Integration devices	CONTROLLER IPASSAN			X	X	X	X	X	V	V	V	V	V
23	Other divices	LIFT INTERFACE FOR IPERCOM SYSTEM	1060/37		X	X	X	X	X	V	V	V	V	V
24	Calling station	CALL MODULE ELEKTA STEEL	1060/23		X	X	X	X	X	X	V	V	V	V
25	Apartment station	VIDEO DOOR PHONE 7" IP VOG7	1761/31-32-33		X	X	X	X	X	X	V	V	V	V
26	Apartment station	VIDEO DOOR PHONE 5" HAND-FREE IPERCOM VOG5	1761/6		X	X	X	X	X	X	V	V	V	V
27	Apartment station	VIDEO DOOR PHONE MAX 10"	1717/21-22-23		X	X	X	X	X	X	V	V	V	V
28	Apartment station	VIDEO DOOR PHONE 7" IPERCOM BASIC	1741/1-2		X	X	X	X	X	X	V	V	V	V
29	Apartment station	IPERCOM CLIENT SOFTWARE FOR WINDOWS PC	1060/43		X	X	X	X	X	X	V	V	V	V
30	Software	Gateway 1060.WIN			X	X	X	X	X	X	X	V	V	V
31	Calling station	MIKRA PLUS PUSH BUTTON PANEL	1060/33		X	X	X	X	X	X	X	X	X	V
32	Calling station	MIKRA DIGITAL PUSH BUTTON PANEL	1060/34		X	X	X	X	X	X	X	X	X	V
33	Apartment station	VIDEO DOOR PHONE IP 5" VOG5+	1761/15-16-18-19		X	X	X	X	X	X	X	X	X	V
34	Integration devices	IPERTALK SERVER	1375/1x-1xA	V1	X	X	X	X	X	X	X	X	X	V

LBT21256

DS1060-195